

# ONVIF™ Uplink Specification

Version 25.12

December, 2025



Copyright © 2008-2025 ONVIF™ All rights reserved.

Recipients of this document may copy, distribute, publish, or display this document so long as this copyright notice, license and disclaimer are retained with all copies of the document. No license is granted to modify this document.

THIS DOCUMENT IS PROVIDED "AS IS," AND THE CORPORATION AND ITS MEMBERS AND THEIR AFFILIATES, MAKE NO REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, OR TITLE; THAT THE CONTENTS OF THIS DOCUMENT ARE SUITABLE FOR ANY PURPOSE; OR THAT THE IMPLEMENTATION OF SUCH CONTENTS WILL NOT INFRINGE ANY PATENTS, COPYRIGHTS, TRADEMARKS OR OTHER RIGHTS.

IN NO EVENT WILL THE CORPORATION OR ITS MEMBERS OR THEIR AFFILIATES BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, ARISING OUT OF OR RELATING TO ANY USE OR DISTRIBUTION OF THIS DOCUMENT, WHETHER OR NOT (1) THE CORPORATION, MEMBERS OR THEIR AFFILIATES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR (2) SUCH DAMAGES WERE REASONABLY FORESEEABLE, AND ARISING OUT OF OR RELATING TO ANY USE OR DISTRIBUTION OF THIS DOCUMENT. THE FOREGOING DISCLAIMER AND LIMITATION ON LIABILITY DO NOT APPLY TO, INVALIDATE, OR LIMIT REPRESENTATIONS AND WARRANTIES MADE BY THE MEMBERS AND THEIR RESPECTIVE AFFILIATES TO THE CORPORATION AND OTHER MEMBERS IN CERTAIN WRITTEN POLICIES OF THE CORPORATION.

## CONTENTS

<b>1 Scope</b>	<b>4</b>
<b>2 Normative references</b>	<b>4</b>
<b>3 Terms and Definitions</b>	<b>4</b>
3.1 Definitions .....	4
3.2 Abbreviations .....	4
<b>4 Overview</b>	<b>5</b>
<b>5 Uplink</b>	<b>5</b>
5.1 Connection Establishment .....	5
5.1.1 Establishing the reverse tunnel .....	5
5.1.1.1 Native h2c-reverse .....	5
5.1.1.2 WebSocket h2c-reverse .....	6
5.1.1.3 HTTP/2 Frames .....	6
5.1.1.4 HTTP Transactions .....	7
5.2 Connection Management .....	7
5.3 Authentication .....	7
5.3.1 mTLS authentication .....	7
5.3.2 Access token authentication .....	7
5.4 Media Streaming .....	8
5.4.1 Introduction .....	8
5.4.2 RTSP over HTTP .....	8
5.4.3 RTSP over WebSockets .....	8
<b>6 Configuration Interface</b>	<b>8</b>
6.1 Configuration parameters .....	8
6.2 GetUplinks .....	9
6.3 SetUplink .....	9
6.4 DeleteUplink .....	10
6.5 Capabilities .....	10
<b>Annex A Revision History</b>	<b>11</b>

## 1 Scope

This document defines the connection protocol for connecting a web service behind a firewall to a client reachable in the internet.

## 2 Normative references

IETF RFC 5246 - The Transport Layer Security (TLS) Protocol, Version 1.2  
<http://tools.ietf.org/html/rfc5246>

IETF RFC 6125 - Representation and Verification of Domain-Based Application Service

Identity within Internet Public Key Infrastructure Using X.509 (PKIX)

Certificates in the Context of Transport Layer Security (TLS)  
<https://tools.ietf.org/html/rfc6125>

IETF RFC 6455 - The WebSocket Protocol  
<https://tools.ietf.org/html/rfc6455>

IETF RFC 6750 - The OAuth 2.0 Authorization Framework: Bearer Token Usage  
<https://tools.ietf.org/html/rfc6750>

IETF RFC 7540 - Hypertext Transfer Protocol Version 2 (HTTP/2)  
<https://tools.ietf.org/html/rfc7540>

IETF RFC 8441 - Bootstrapping WebSockets with HTTP/2  
<https://tools.ietf.org/html/rfc8441>

ONVIF Core Specification  
<http://www.onvif.org/onvif/specs/core/ONVIF-Core-Specification.pdf>

ONVIF Media2 Service Specification  
<https://www.onvif.org/specs/srv/media/ONVIF-Media2-Service-Spec.pdf>

ONVIF Security Service Specification  
<https://www.onvif.org/specs/srv/security/ONVIF-Security-Service-Spec.pdf>

ONVIF Streaming Specification  
<https://www.onvif.org/specs/stream/ONVIF-Streaming-Spec.pdf>

Apple Computer Inc. RTSP over HTTP, Tunneling QuickTime RTSP and RTP over HTTP  
[https://opensource.apple.com/source/QuickTimeStreamingServer/QuickTimeStreamingServer-412.42/Documentation/RTSP\\_Over\\_HTTP.pdf](https://opensource.apple.com/source/QuickTimeStreamingServer/QuickTimeStreamingServer-412.42/Documentation/RTSP_Over_HTTP.pdf)

## 3 Terms and Definitions

### 3.1 Definitions


<b>Local Service</b>	A service to be used by a client behind a firewall.
<b>Remote Client</b>	A client that wants to access a service that is located behind a firewall.
<b>Uplink</b>	The connection establish by the local service to the remote client.

### 3.2 Abbreviations


HTTP	Hypertext Transfer Protocol
TLS	Transport Layer Security

## 4 Overview

The ONVIF connection protocols base on the standard web service model where the client initiates a connection to a device as depicted in Figure 1..



**Figure 1: Standard connection initiated from the client**



**Figure 2: Connection initiation from the device**

This document specifies a solution that allows a camera to use an uplink to facilitate existing web server and RTSP server functionality using the http/2 protocol.

## 5 Uplink

### 5.1 Connection Establishment


There are two connection mechanisms available for a device to connect to a remote client. The device can either use an http/2 reverse tunnel or a WebSocket.

#### 5.1.1 Establishing the reverse tunnel

The device initiates the connection to the cloud service. This is done in three phases. Phase 2 and 3 depend on the protocol being used and are detailed below. In the first phase the device acts as TLS client that connects to the cloud service. Details of the TCP and TLS exchange are out of scope of this specification.

##### 5.1.1.1 Native h2c-reverse

The second phase includes the connection upgrade to HTTP/2 h2c-reverse protocol which is confirmed by the cloud service with a 101 HTTP response. The third phase of the connection then fully complies to an HTTP2 connection as if it were initiated from the cloud service. Please note that the figure only shows the most relevant packets.




**Figure 3: Connection initiation from the device**

This protocol shall be used when the uri protocol states 'https'. A device signaling support for https via its Protocol capability shall support native h2c-reverse.

#### 5.1.1.2 WebSocket h2c-reverse

The second phase includes the connection upgrade to a WebSocket with the reverse HTTP2 subprotocol which is confirmed by the cloud service with a 101 HTTP response. The third phase of the connection then corresponds to an HTTP2 connection as if it were initiated from the cloud services, using WebSocket binary frames. Please note that the figure only shows the most relevant packets. You may provide an access token by adding a query parameter to the WebSocket URI as defined by [RFC6750] Section 2.3.



**Figure 4: Connection initiation over websocket**

This protocol shall be used when the uri protocol states 'wss'. A device signaling support for wss via its Protocol capability shall support h2c-reverse over WebSocket.

#### 5.1.1.3 HTTP/2 Frames

Once an http/2 connection has been established the communication parameters are negotiated as specified by RFC 7540 so that the uplink can be used to exchange frames between the remote client and the local service.

### 5.1.1.4 HTTP Transactions

The uplink shall be used in reverse direction for http requests and responses. The remote client shall send requests that are served in a standard http manner by the local service.

## 5.2 Connection Management

A local service that is offered to a remote client for utilization is responsible for maintaining an operational communication channel. Since the connection needs to be established from the service to the remote client this connection is called uplink. The uplink shall be secured via TLS.

The local service shall monitor whether the remote client is able to communicate via the uplink. It may use the HTTP/2 ping mechanism to check whether a link is still operational if no packets have been received for a longer period of time.

The local service shall close and reconnect the uplink whenever no packets have been received from the remote client for more than 30 seconds. Each camera shall use an individual ascending interval strategy to avoid that all cameras connect at the same time.

The following example shows patterns chosen by two cameras A and B:

- Camera A: 3s, 6s, 12s, 24s, 30s, 30s ...
- Camera B: 2s, 4s, 8s, 16s, 30s, 30s ...

If multiple uplink configurations are included, the device shall try to establish all connections from the list and maintain those connections in parallel.

Note that this specification expects different clients may try to reach multiple local services and it is assumed services and clients are designed such that they do not interfere with each other. The coordination between such multiple clients and services is outside of the scope of the specification.

## 5.3 Authentication

Note that for the following discussion the roles of client and server are swapped.

The remote client shall authenticate itself using a valid server certificate. The local service shall verify the validity of the remote certificate according to RFC 6125.

The device shall assign any tunneled HTTP or RTSP request the UserLevel that is configured for the configuration without the need of further authentication request headers.

### 5.3.1 mTLS authentication

Device signaling support for mTLS based authentication shall include `mTLS` in the list of `AuthorizationModes` of `GetServiceCapabilities` response.

When using mTLS authentication, the local service shall authenticate itself at the remote client using TLS client authentication according to RFC 5246 or subsequent specifications.

To uniquely identify a local service on remote client, it is recommended to have a unique client certificate installed on each local service. For example, CN field or Serial number of installed certificate could be used to uniquely identify the local service.

### 5.3.2 Access token authentication

Device signaling support for access token based authentication shall include `AccessToken` in the list of `AuthorizationModes` of `GetServiceCapabilities` response. Device shall signal value greater than 0 for `AuthorizationServer.MaxConfigurations` in `GetServiceCapabilities` response from the Security service.

To authenticate with the remote client or service, the local service shall include the access token retrieved from the configured `AuthorizationServer` in the `Authorization` header when sending the upgrade request.

The remote client shall validate the access token.

## 5.4 Media Streaming

### 5.4.1 Introduction

The ONVIF Media Service Specification and the ONVIF Streaming Specification define various mechanisms for streaming Video, Audio and Metadata. This specification defines how to apply streaming over http/2. Usage of other communication mechanisms like UDP unicast and multicast are outside of the scope of this specification.

ONVIF recommends to use WebRTC based media streaming for low latency peer to peer streaming use cases rather than media streaming over Uplink. ONVIF specified streaming over WebRTC is outside the scope of this specification.

### 5.4.2 RTSP over HTTP

The underlying RTSP over HTTP specification requires to open separate communication channels for continuously sending and receiving data. For sending media from RTSP server to client the communication channel is opened with a GET request and a response without content-length. For sending media to the server a POST request is used. The specification notes that a content-length must be sent. Most applications use the value 32767 from the example given in the specification. Since http/2 streams may be closed by either side when the content-length has been reached clients shall use a value large enough for the connection life time.

A device shall support media streaming over uplink via RTSP over HTTP or RTSP over WebSockets if StreamingOverUplink capability is supported.

A device signaling support for RTSP streaming via its capability RTSPStreaming should support the same on the uplink.

### 5.4.3 RTSP over WebSockets

A device shall support media streaming over uplink via RTSP over HTTP or RTSP over WebSockets if StreamingOverUplink capability is supported.

A device signaling support for websockets over RTSP via its capability RTSPWebSocketUri should support RFC 8441 on the uplink.

## 6 Configuration Interface

### 6.1 Configuration parameters

Table 1: Parameters description

Parameter	Description
RemoteAddress	Uniform resource locator by which the remote client can be reached.
CertificateID	ID of the certificate to be used for client authentication.  If the CertificateID is present in the UplinkConfiguration the device shall use mTLS authentication mechanism.
UserLevel	Authorization level that will be assigned to the uplink connection.  In case the device signals support for user roles through the MaxUserRoles capability, UserLevel may contain a list of acceptable user roles.
Status	Current connection status
CertPathValidationPolicyID	CertPathValidationPolicyID used to validate the uplink server certificate. If not configured, server certificate validation behavior is undefined and the device may either apply a vendor specific default validation policy or skip validation at all.

Parameter	Description
AuthorizationServer	AuthorizationServerConfiguration token referring to an authorization server that provides an access token to authorize with the uplink server.  If the AuthorizationServer token is present in the UplinkConfiguration the device shall use access token authentication mechanism.
Error	Optional user readable error information (readonly).

The device shall interpret the field RemoteAddress as key to a specific uplink configuration.

## 6.2 GetUplinks

A device supporting uplinks shall support this command to retrieve the configured uplink configurations. The Status field shall signal whether a connection is Offline, Connecting or Online.

REQUEST:

This message is empty

RESPONSE:

- **Configuration – optional, unbounded [Configuration]**  
List of configurations.

ACCESS CLASS:

**READ\_SYSTEM**

## 6.3 SetUplink

A device supporting uplinks shall support this command to add or modify an uplink configuration. The Status property of the UplinkConfiguration shall be ignored by the device. A device shall use the field RemoteAddress to decide whether to update an existing entry or create a new entry. A device shall reject a configuration containing both CertificateID and AuthorizationServer.

REQUEST:

- **Configuration – [UplinkConfiguration]**  
Configuration to be added or modified.

RESPONSE:

This message is empty

FAULTS:

- **env:Sender - ter:InvalidArgVal - ter:CertificateID**  
No certificate is stored under the requested CertificateID.
- **env:Sender - ter:InvalidArgVal - ter:CertPathValidationPolicyID**  
No certificate validation policy is stored under the requested CertPathValidationPolicyID.
- **env:Sender - ter:InvalidArgVal - ter:AuthorizationServerConfigurationToken**  
No AuthorizationServerConfiguration exists for the specified token.
- **env:Sender - ter:InvalidArgs - ter:MissingAuthentication**  
CertificateID and AuthorizationServerConfigurationToken are both missing.
- **env:Sender - ter:InvalidArgs - ter:AmbiguousAuthentication**  
CertificateID and AuthorizationServerConfigurationToken are mutually exclusive.

- **env:Sender - ter:InvalidArgs - ter:ProtocolNotSupported**

The provided protocol is not supported by the device.

ACCESS CLASS:

**WRITE\_SYSTEM**

#### 6.4 DeleteUplink

A device supporting uplinks shall support this command to remove an uplink configuration.

REQUEST:

- **RemoteAddress – [xs:anyURI]**

Configuration to be deleted.

RESPONSE:

This message is empty

FAULTS:

- **ter:Sender - ter:InvalidArgVal - ter:Address**

No uplink exists for the given address.

ACCESS CLASS:

**WRITE\_SYSTEM**

#### 6.5 Capabilities

**MaxUplinks** Maximum number of uplink connections that can be configured

**Protocols** Supported protocols [https, wss]

**AuthorizationModes** Supported authorization mode [mTLS, AccessToken]

**StreamingOverUplink** Signals support for media streaming over uplink

## Annex A. Revision History

Rev.	Date	Editor	Changes
18.12	Dec 2018	Hans Busch	First release
22.06	June 2022	Hans Busch	Add section on media streaming
23.06	June 2023	Hans Busch	Clarify authentication within the established tunnel.
23.12	Dec 2023	Hans Busch	Add error codes.
24.06	Jun 2024	Jean-Francois Levesque	Add support for WebSocket protocol and token authorization.
24.12	Dec 2024	Sriram Bhetanabotla	Improve certificate verification policy and correct specification references.
25.06	Jun 2025	Jean-Francois Levesque, Sriram Bhetanabotla	Clarify misuse of JWT in Uplink and WebRTC specs. Make uplink streaming not mandatory
25.12	Dec 2025	Ottavio Campana	Add support for user roles.